

St. John In Bedwardine Church, Bromyard Road, Worcester

Potential Programme of Works

- 1) Investigate and cut trap in Muniment room ceiling.
- 2) Remove bell wheels, straps etc. and set aside for reuse.
- 3) Provide deck on top of bell frame to allow repairs to roof.
- 4) Cut out pockets and cast padstones and insert new steel beams below roof support timbers. This will provide support for roof and can also be used to lift and lower bells.
- 5) Lower bells to floor of church and store in North Aisle.
- 6) Strip lead from roof gutters and tiles from roof.
- 7) Inspect roof timbers and carry out replacement of defective timbers, (anticipate replacement of wall plate, rafter feet and gutter supports.)
- 8) Install new lead gutters and re tile roof.
- 9) Hoist/raise bell frame for inspection of foundation beams and remove floor boards between frame and beams.
- 10) Carry out repairs to foundation beams as required.
- 11) Cut wall pockets, cast padstones and install new steel beams to support timber foundation beams.
- 12) Fix new floor boarding between frame and beams.
- 13) Lower bell frame into place and fix.
- 14) Construct new insulated ceiling under bell frame.
- 15) Hoist bells and re hang.